

1 FIXINGS SUPPLIED

- 4x 14g x 45 MASONRY SCREWS



- 4x M6x16 BLACK
BUTTON HEAD SCREWS




2 TOOLS REQUIRED


- LEVEL
- ADJUSTABLE WRENCH /5/16" HEX HEAD SOCKET
- DRILL WITH HAMMER SETTING
- STICKY TAPE / MOUNTING TACK
- 3/16" MASONRY SCREW BIT
- ALLEN KEY

3 INSTALLATION:

1. STICK THE TOP CORNERS OF THE DRILLING TEMPLATE TO THE WALL.




2. MAKE SURE THE TEMPLATE IS LEVEL USING THE TOP LINE OF THE G-FORCE LOGO. ADJUST AS REQUIRED AND SECURE THE BOTTOM CORNERS.



3. PRE-DRILL / MARK THE CIRCLED FIXING LOCATIONS, SHOWN BELOW.


NOTE: NOT TO BE FIXED INTO MORTAR BETWEEN BRICKS.




4. REMOVE THE TEMPLATE AND FINISH DRILLING PILOT HOLES AS REQUIRED. DRILL TO A DEPTH 10mm DEEPER THAN SCREW.

- ATTACH THE MOUNTING PLATES TO THE WALL USING THE FOUR 45mm MASONRY SCREWS. DO NOT FULLY TIGHTEN YET. CONFIRM THAT THE MOUNTING PLATES ARE LEVEL BEFORE FULLY TIGHTENING.

NOTE: DO NOT OVER-TIGHTEN.



- MOUNT THE MAIN FRAME ON THE MOUNTING BRACKET USING THE FOUR BLACK BUTTON HEAD SCREWS, START WITH THE TOP TWO SCREWS. TIGHTEN ALL SCREWS TO FINGER TIGHT. CONFIRM THE RACK IS LEVEL AND TIGHTEN FULLY USING ALLEN KEY.



- YOU ARE NOW READY TO RACK IT!**